



## 480VAC PACKAGES, 3-PHASE

EIM MODEL	LOAD HP	LOAD AMPS	DESCRIPTION	DISTRIBUTOR PRICING
EIM-CMS005-3-480	5	8	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	Call for Pricing
EIM-CMS007-3-480	7	12	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS010-3-480	10	16	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS015-3-480	15	23	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS020-3-480	20	30	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS025-3-480	25	37	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS030-3-480	30	45	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS040-3-480	40	61	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS050-3-480	50	78	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS060-3-480	60	92	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS075-3-480	75	107	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	
EIM-CMS100-3-480	100	142	CUSTOM COMBINATION STARTER WITH MAIN BREAKER	

ALL COMBINATION MOTOR STARTERS INCLUDE: NEMA 4 CABINET, MAIN BREAKER W/HANDLE, STARTER, OVERLOAD, CONTROL TRANSFORMER, ON/OFF SWITCH, HOA SWITCH, AUTO RELAY, INPUT BLOCKS.